

SONY.

Compact Disc Player



CDP-557ESD CDP-707ESD CDP-337ESD

Operating Instructions Page 2

Before operating the unit, please read this manual thoroughly and retain it for future reference.

Mode d'emploi Page 30

Avant la mise en service de cet appareil, prière de lire attentivement ce mode d'emploi que l'on conservera pour toute référence ultérieure.

Manual de instrucciones Página 58

Antes de utilizar la unidad, lea este manual detenidamente y consérvelo para futuras referencias.



Photo: CDP-707ESD



Photo: CDP-337ESD

Warning

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

DANGER

Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT label is located on the rear exterior.

Laser component in this product is capable of emitting radiation exceeding the limit for Class 1.

NOTICE FOR THE CUSTOMERS IN THE UNITED KINGDOM

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

FOR THE CUSTOMERS IN CANADA

CAUTION:

TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

Differences among the CDP-557ESD, the CDP-707ESD and the CDP-337ESD

This instruction manual covers the CDP-557ESD, the CDP-707ESD and the CDP-337ESD. Their performance and operation are identical. They differ only in their front panel design and technical specifications. As for the specifications, refer to "Specifications".

The following models are supplied with the side panels, while the other models are not:

CDP-707ESD (for U.S.A. and Canada)
CDP-557ESD (for European countries)

The illustrations used in this manual are of the CDP-707ESD.

Table of Contents

Getting Started

Note on the transit screw	4
When you use the CD player for the first time	4
Features	5
Precautions	5
Operating voltage	5
Installation	6
Connections	7
Description on the rear panel	7
Notes on connection	7
Connection diagram	8
Location of controls	10

Basic operation

Playing a disc	12
Locating a particular selection	13
Locating a particular point in a selection	13
Playing a single selection	14
Stopping play for a moment automatically at the beginning of each selection	14
Inserting a blank space between selections	14

Advanced operation

Playing in the desired order	15
Playing in a random order	18
Playing repeatedly	19

Custom file operation

On custom files	20
Writing a comment about a disc	21
Keeping the program in memory	23
Giving a disc indexes as you want	24

Other way to use

Timer activated playing	25
-------------------------	----

Maintaining your Unit

Maintenance	27
-------------	----

Getting into the Details


Specifications	27
----------------	----

Troubleshooting

Troubleshooting guide	29
-----------------------	----

Note on the Transit Screw

Turn the transit screw
down to turn the screw.




Before operating the CD player, be sure to turn the transit screw as described on the label on the bottom of the unit.

- 1 Remove the cap of the screw.
- 2 Turn the screw 180 degrees counterclockwise using the supplied screwdriver.

Do not turn the screw excessively, or the unit may be damaged.

When transporting the unit again, turn the transit screw in the reverse direction.

When You Use the CD Player for the First Time



Turn on the power by pressing POWER while keeping ERASE and FILE pressed.

This will clear the internal memory if you have been instructed how to use the custom file function at the shop you purchased the CD player. Thus the player returns the same status as it was manufactured at factory.

Features

Custom file function

- **Disc memo function** for writing a comment about a disc. (page 21)
- **Program bank function** for storing a programmed playing order. (page 23)
- **Custom index function** for assigning your own index point to any desired position on a disc. (page 24)

Program play

You can play up to 20 selections in the desired order. Pause can be also programmed. You can also confirm the total playing time while choosing the selection to be programmed.

Variety of playing modes

Single play (page 14), program play (page 15), shuffle play (page 16) and repeat play (page 19) as well as normal continuous play of a whole disc.

Large and easy-to-read window display

Shows the elapsed playing time, the remaining time of the selection being played, the remaining time of the whole disc or the remaining programmed selection numbers. The display contains a music calendar indicating all the numbers of the selections on the disc (up to 20).

Precautions

On safety

- Before operating the unit, be sure that the operating voltage of your unit is identical with that of your local power supply.
- Should any liquid or solid object fall into the cabinet, unplug the unit and have it checked by qualified personnel before operating it any further.
- Unplug the unit from the wall outlet if it will not be used for a long time. To disconnect the cord, pull it out by grasping the plug. Never pull the cord itself.
- The nameplate indicating operating voltage, power consumption, etc. is located on the rear of the unit.
- As the laser beam used in this compact disc player is harmful to the eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

On operation

When the unit is not used, turn the power off, to conserve energy and to extend the useful life of your unit.

Important

Since the CD system boasts a wide dynamic range, the peaks of high level inputs are recorded with high fidelity, and the noise level is very low.

Do not turn up the volume while listening to a portion with no audio signals or very low level inputs. If you do, the speakers may be damaged when a peak level portion is played.

If you have any questions or problems concerning your unit, please contact your nearest Sony dealer.

Operating Voltage

Before connecting the unit to the power source, check that the operating voltage of your unit is the same as the local power line voltage.

Model	Where purchased	Operating voltage
CDP-557ESD CDP-337ESD	European countries	Operates on 220V AC (or 240V AC adjustable by authorized Sony personnel), 50/60Hz
	United Kingdom	Operates on 240V AC (or 220V AC adjustable by authorized Sony personnel), 50 Hz
CDP-707ESD	U.S.A. and Canada	Operates on 120V AC, 60 Hz

Model	Where purchased	Operating voltage
CDP-337ESD	Other countries	Operates on either 120, 220 or 240 V AC, 50/60 Hz. The voltage selector is located on the rear panel. If the selector must be reset, disconnect the AC power cord and turn the selector with a coin or a similar object so that the arrow mark of the selector points to the proper voltage figure.




Installation

Notes on Installation

Place the unit in a location with adequate air circulation to prevent internal heat build-up in the unit.

This way.



Do not place the unit on a soft surface, such as a rug that would block the ventilation holes on the bottom.

Not this way.




Do not install the unit:

- near heat sources such as radiators or air ducts,
- in a place subject to direct sunlight, excessive dust, mechanical vibration or shock.


Installing Batteries

Install the batteries in the supplied remote commander for remote control operation.

1



2



On moisture condensation

If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the unit.

Should this occur, the player will not operate. In this case, remove the disc and leave the player turned on for about an hour until the moisture evaporates.

Do not throw away the carton and the packing material
It will be an ideal container when transporting the unit for repair work, etc.

To avoid damage caused by battery leakage and corrosion
When the commander will not be used for a long time, remove the batteries.



On battery life

About half a year of normal operation can be expected when using the Sony SUM-3 (NS) batteries.

When the batteries are run down, the remote commander will not operate the unit. In this case, replace both batteries with new ones.

Connections

Description on Rear Panel



1 LINE OUT (audio output) jacks

FIXED: Output the signal at the fixed level.

VARIABLE: Output the signal at the level set by the LINE OUT/HEADPHONE LEVEL control (or LINE OUT VOLUME buttons on the remote commander).

2 OUTPUT SELECTOR

Selects the output connectors to be used.

DIGITAL OUT: Digital signal is output through the DIGITAL OUT jacks. No signal is output through the LINE OUT jacks or the HEADPHONES jack.

LINE OUT: Audio signal is output through the LINE OUT jacks or the HEADPHONES jack. No signal is output through the DIGITAL OUT jacks. (Be sure to set to this position when you listen to the music through the headphones or the LINE OUT jacks.)

3 DIGITAL OUT (digital audio output) jacks

Output the digital audio signals.

COAXIAL: To be connected to a digital input jack of the amplifier or the D/A converter unit.

OPTICAL: To be connected to the amplifier having an optical input jack.

Note: If the LINE OUT/HEADPHONE LEVEL control is turned while recording through the VARIABLE LINE OUT jacks, the level of the recorded sound will be different from that set by the recording level controls of the tape deck.


Notes on Connection

- Turn off the amplifier before making connections.
- Be sure to insert the plugs firmly into the jacks. Loose connections may cause hum and noise.
- Leave a little slack in the connecting cord to allow for inadvertent shock or vibration.
- Connect the red plug of the supplied connecting cord to the right-channel jack (R) of the amplifier and the white plug to the left-channel jack (L). Otherwise, the right and left channels will be reversed.

Connection


Connection Diagram

Connecting the amplifier directly



Connecting D/A converter unit and amplifier


Sony DAS-702ES D/A converter unit or other equivalent D/A converter using a digital audio interface can be connected to the **DIGITAL OUT** jack.



*Digital signal is output through the **DIGITAL OUT** jack. In this case, sound does not come through the **LINE OUT** jacks and the **HEADPHONES** jack.

Connecting an amplifier having an optical input connector

Illustration: GDP-707ESD




Location of Controls

Front Panel


Refer to the pages indicated in ● for details.

The illustration shows the front panel of the CDP-557ESD/CDP-707ESD. The front panel design of the CDP-337ESD is slightly different, but locations and function of the controls are identical.



* AMS is an abbreviation of Automatic Music Sensor.

Remote Commander



Remote Control Operation

Once the POWER switch is turned on, you can remotely control various functions of the player with the supplied remote commander.

Operations which is performed only with the remote commander

- Manual search at low speed
- A → B repeat

Operations which cannot be performed with the remote commander

- Turning the power on and off
- Setting and releasing auto pause function
- Setting and releasing auto space function
- Checking the programmed selections
- Writing a comment about a disc
- Clearing custom indexes
- Clearing all custom files
- Timer activated play


Notes on the remote commander and remote control operation

- Keep the commander away from extremely hot or humid places.
- Avoid dropping any foreign objects into the commander casing, particularly when replacing the batteries.

- To avoid a malfunction, do not simultaneously depress two or more buttons.
- Avoid exposure of the remote sensor to direct sunlight or lighting apparatus. Such exposure can cause a malfunction.

Playing a Disc

Before playing a disc, turn on the amplifier and set the input selector to the CD player position.



1 Depress POWER.

If "SINGLE" is displayed in the window, or if the lamp on the PROGRAM or SHUFFLE button is lit, press CONTINUE/SINGLE.

2 Press ▲ and put the disc in the disc compartment with the label side up.

3 Press ►.

The compartment closes and play begins from the beginning of the disc.

Selection No. being played Elapsed playing time Music calendar



When a disc containing more than 20 selections is inserted, **OVER20** appears.

Stopping play

To stop for a moment during play	Press II. To restart play, press II again.
To stop play	Press III.
To stop play and open the compartment	Press ▲. To close the compartment, press ▲ or the compartment itself.

To enter pause instead of starting play

Press II instead of ►. The disc compartment closes and the player enters the pause mode at the beginning of the first selection. To start play, press II again.

To display the remaining time of the current selection
Press DISPLAY once during play or pause.



To return to the normal display, press DISPLAY twice, or three times if a disc memo* is memorized.

* See page 21.

To display the remaining number of selections and the remaining time of the disc
Press DISPLAY twice.



To return to the normal display, press DISPLAY once, or twice if a disc memo is memorized.

"EMPHASIS" indication appears when

The built-in de-emphasis circuit is turned on. If a disc recorded with the recording level of high frequencies raised is played, the circuit is turned on automatically and lowers the level of high frequencies. This improves the signal-to-noise ratio of high frequencies.

Locating a Particular Selection

Locating a selection in sequence (Automatic Music Sensor)

You can locate the beginning of a desired selection during play.

To locate the beginning of the selection being played	Press ◀◀ once.
To locate the beginning of the next selection	Press ▶▶ once.

Press continuously to locate previous selections or selections ahead.

Locating a selection directly

Press one of the numeric buttons (1 to 20) to enter the desired track number.

Locating a Particular Point in a Selection

Locating a point in sequence (Manual Search)

You can locate a particular point in a selection during play by monitoring the high-speed sound.

To go back at high speed	Keep ◀◀ pressed.
To go ahead at high speed	Keep ▶▶ pressed.

Release the button at the desired point.

Locating at a lower speed

Press **◀◀▶▶** [SLOW] on the remote commander.

Locating an Index*

This function is only possible with a disc on which index numbers are recorded.

Press **◀** or **▶** to locate the desired index number. The selected index number appears in the display window.

When locating a particular selection

If "SINGLE" is displayed in the window, or if the lamp on the PROGRAM or SHUFFLE button is lit, press CONTINUE/SINGLE.

To choose directly a selection whose number is greater than 20 Use the **[>20]** button and **[1]** to **[10]** buttons. **[10]** button functions as the figure 0.

Ex. To play from track No.32

Press **[>20]** → **[3]** → **[2]**

Ex. To play from track No.30

Press **[>20]** → **[3]** → **[10]**

To locate at high speed

Press **◀◀** or **▶▶** in the pause mode. The search speed increases by three times, but there is no sound. Find the desired point by observing the display.

If you continuously press **◀◀▶▶**

If you continuously press **▶▶** at the end of the disc, "OVER" appears in the window. Press **◀◀** or **◀** to go back to normal indication.

If you continuously press **◀◀** at the beginning of the disc, play begins automatically from the first selection.

*What is index?

The selections on some discs are divided into sections, such as the movements of a symphony. An index number is assigned to each section thus making it possible to find a particular section easily.

Playing a Disc

Playing a Single Selection—Single Play

You can play only one desired selection.

- 1 Press **CONTINUE/SINGLE** on the player (or **SINGLE** on the remote commander) to display "SINGLE" in the window.
- 2 Start playing the desired selection by pressing the numeric buttons, or by pressing **◀◀▶▶** and then **▶**. Playing stops when the chosen selection ends.

To cancel single play

Press **CONTINUE/SINGLE** on the player (or **CONTINUE** on the remote commander) so that "SINGLE" disappears from the window.

Stopping Play for a Moment Automatically at the Beginning of Each Selection—Auto Pause Function

Press **A. SPACE/PAUSE** so that "AUTO PAUSE" is displayed in the window.

To restart play

Press **II**.

To cancel the auto pause function

Press **A. SPACE/PAUSE** once so that "AUTO PAUSE" disappears.

Inserting a Blank Space between Selections—Auto Space Function

A blank space of approx. 3 seconds can be inserted between selections.

If you record on a tape using this function, the automatic music sensor of the deck used to play back the tape will function correctly.

Press **A. SPACE/PAUSE** so that "AUTO SPACE" is displayed in the window.

To cancel the auto space function

Press **A. SPACE/PAUSE** twice so that "AUTO SPACE" disappears.

To play only the first selection

Display "SINGLE" in the window, and press **▶**.

Notes on discs

Handle the disc by its edge, and to keep the disc clean, do not touch the surface.

Do not stick paper or tape.



This way




Not this way

Do not expose the disc to direct sunlight or heat sources such as hot air ducts, or leave it in a car parked in direct sunlight where there can be a considerable rise in the temperature.

Playing in the Desired Order—Program Play


You can play up to 20 selections in the desired order.

Programming Selections Directly



1 Press PROGRAM.

2 Press the numeric buttons for the desired selection in the order to be programmed.



The total playing time

To play the programmed selections
Press ►.

Adding selections to a program during program play

Press the numeric buttons during play. You can add selections up to 20.

- Pause cannot be programmed during play.

When each selection ends during program play
That selection number disappears from the display, but the program itself remains. If you press ►, you can play the same program again.

Note

If you press PROGRAM during the continuous play, single play or shuffle play (page 18), the selection currently being played is programmed as the first selection in the program.

Program is cleared in the following cases.

- ■ is pressed twice during program play.
- CONTINUE/SINGLE, SHUFFLE or ■ is pressed.

Space between selections during program play

There is a blank of 1 second between each programmed selection. However, when consecutive selections (e.g. 4th → 5th) are programmed, the space on the disc is inserted as it is. To record program play on a tape, use the auto space function (page 14) so that a blank of 3 seconds is inserted between selections.


What is this indication?

"----" indication appears on the display window instead of the numbers, if a selection numbered 21 or higher is programmed or the total playing time of the programmed selection exceeds 100 minutes.

Playing in the Desired Order—Program Play

Programming Selections while Checking the Total Programming Time (Program Edit)

This function is useful for recording, as you can adjust the total playing time to the tape duration.



1 Press PROGRAM.

2 Choose the desired selection to be programmed with ◀◀ or ▶▶.
The designated selection number blinks in the music calendar.

Selection No. Program No.



The total playing time including the selection indicated.

If the playing time of that selection is not appropriate, choose another selection.

3 Press PROGRAM.

The designated selection is programmed and the blinking number lights up steadily.


4 Repeat steps 2 and 3 to program additional selections in the desired order.

To play the programmed selections
Press ▶.

To program pause

During programming, press II at the desired point between selections. When the program reaches it, the disc stops and stands by until you press II again.

This function is helpful when changing the tape during recording. The total playing time will be reset to 0:00 when you press II.



P (pause) has been programmed.
Its turn is third.

Checking the Programmed Selections

(possible only on the main unit)

Press **CHECK**.

Each time you press **CHECK**, the selections are displayed in the order they are programmed. At the last selection, "END" is displayed.

- You can check the programmed selections during play.
- Selection numbers over 20 cannot be displayed in the music calendar, but track numbers and program numbers are displayed in the window.

Clearing the Programmed Selections

Clearing the whole program

Press **■** once during stop, or twice during play.

All the selections are cleared.

Clearing the last selections in the program

(operated only on the main unit)

Press **CLEAR** during stop.

The last selection is cleared each time **CLEAR** is pressed.

Clearing a specific selection

(possible only on the main unit)

- 1 Press **CHECK** repeatedly until the selection to be cleared is displayed.
- 2 Press **CLEAR** while the selection number is displayed.
The selection is cleared from the program.
You cannot clear the selection currently being played.

To display the remaining number of selections and time of the program:

Press **DISPLAY** twice.



If pause is programmed, the remaining number of selections and time to the next programmed pause is displayed.

To return to the normal display, press **DISPLAY** twice, or three times (if a disc memo* is memorized).

* See page 21.

To display the next selection number and the succeeding selection number in the program:

Press **DISPLAY** three times.




To return to the normal display, press **DISPLAY** once, or twice (if a disc memo is memorized).

Playing in a Random Order—Shuffle Play

You can play up to 99 selections in a random order.


Playing All the Selections in a Random Order




- 1 Press SHUFFLE.
- 2 Press ►.
Shuffle play begins.

To cancel shuffle play mode
Press CONTINUE/SINGLE (or CONTINUE on
the remote commander).

Playing Only the Desired Selections in a Random Order—Delete Shuffle Play



- 1 Press SHUFFLE.
- 2 Press the numeric buttons of the undesired
selections you wish to delete.
The selections disappear from the music
calendar.



- 3 Press ►.

What is this indication?



This indication appears while the player is "shuffling"
the selections.

If you press SHUFFLE during play
Shuffle play begins from the selection being played.

To record shuffle play

During shuffle play, a blank of one second is inserted between
each selection.

To record shuffle play, use the auto space function (page 14) so
that a blank of 3 seconds is inserted between selections.

When delete shuffle play ends

Delete shuffle play mode is released and the player stands by in
the shuffle play mode for the whole disc.

If you press the numeric buttons during shuffle play mode
The selections of those numbers are also deleted, but the
selection being played cannot be deleted.

To play a selection which has been deleted

Press the numeric button of that selection again.
The selection number and **DN** appear in the display.

Playing Repeatedly—Repeat Play



You can repeat the whole disc, a single selection, all the programmed selections, shuffle play, A $\leftrightarrow$ B repeat play, or play between two custom indexes.

Press REPEAT during play or pause. Repeat play begins according to the current play mode.

Play mode	Selections to be repeated
Continue	All the selections
Single	The selection being played
Program	Programmed selections in the programmed order
Shuffle	All the selections, reshuffled each time

For A $\leftrightarrow$ B repeat play, see the heading on below.
For the repeat play between two custom indexes, see page 25.

To cancel repeat play mode
Press REPEAT.

Repeating a Particular Portion (A $\leftrightarrow$ B Repeat)

(Possible with the remote commander)
You can repeat any desired portion on a disc.

- 1 Press A $\leftrightarrow$ B at the starting point (A) of the repeat play.
"A SET" appears in the window.
- 2 Continue playing, or press $\blacktriangleright$ or $\blacktriangleleft$ to locate the desired ending point (B).
- 3 Press A $\leftrightarrow$ B.
"A - B REP" appears in the window, and play begins from the point A.

To cancel A $\leftrightarrow$ B repeat
Press CLEAR/REPEAT (or REPEAT on the player).

Going back to the point A from any point on the disc

- 1 Press A $\leftrightarrow$ B at the starting point (A) during play.
- 2 Press $\blacktriangleleft$ when you desire to return to the registered point. Play begins again from the point A.

A $\leftrightarrow$ B repeat and auto pause function

If the A $\leftrightarrow$ B repeat play is activated while the auto pause function is turned on, the player enters the pause mode each time the point A is reached. Press II to resume play.

To go back to the point A during A $\leftrightarrow$ B repeat play
Press $\blacktriangleleft$.

If you press REPEAT during delete shuffle play
When the desired selections end, repeat play of all the selections starts.

On Custom Files

The CD player incorporates a memory in which you can store three types of informations called "custom files".

Three custom files you can store in memory

Disc memo	A comment of up to 10 letters, which you can assign to each individual disc. (page 21)
Program bank	A programmed playing order you store in memory for a disc, so that the disc can be played always in a fixed order. (page 23)
Custom index	Index point you can assign to anywhere you want on a disc. (page 25)

How many discs can be assigned custom files?

You can give custom files to up to 226 discs.

- A disc memo can be given to a disc which already has a program bank or custom indexes.
- A program bank and custom indexes cannot both be given to a disc at the same time.

Memory backup for the custom files

Custom files, once memorized, are retained in the compact disc player's memory for approximately 1 month without AC power supply.

What is this indication?

FULL
FULL

This indication appears when FILE is pressed while no custom file can be memorized for the disc currently put in the player. To make a custom file for the disc, clear the custom file of another disc.

To clear all custom files of a disc at once

Put the disc in the player and press ERASE. The disc memo and program bank (or the disc memo and custom indexes) are all cleared.


To clear custom files of all discs at once

Press POWER to turn on the player while keeping ERASE and FILE pressed.

Writing a Comment about a Disc

—Disc Memo Function

Using the disc memo function, you can write a comment of up to 10 letters about a disc. The memo appears in the window every time you put the disc in the player. You can write one disc memo to a disc.




1 Put the disc in the disc compartment and press the disc compartment to close it. Make sure that the total number of selections and the total playing time is displayed. Then proceed as follows in the stop mode.

2 Press **◀** or **▶**.
A blinking cursor (indicating where a letter will be written) appears.

3 Press **◀** or **▶** until the desired letter appears.
Example: If **▶** is pressed 6 times



4 Press **▶** to move the cursor to the next position, and select the desired letter.



Repeat steps 3 and 4 to complete the memo.

5 Press **FILE**.
"FILE" appears in the window. After about 1 second, the memo you have written will be displayed.

Each time the disc is put in the compact disc player, the memo will be displayed.

Usable letters and symbols

For the disc memo, 46 letters and symbols and a space can be used. When the **◀▶** button is pressed for the first time, the space appears. Each time **▶** is pressed, letters and symbols will appear in the following order.

{space} A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
[] _ * ^ + / > < 0 1 2 3 4 5 6 7 8 9 -

Use **◀** to call up a previous character.

To rewrite letters or symbols

Before pressing **FILE**, move the cursor under the letter/symbol to be changed, and then select the desired letter/symbol using **◀▶**.

Writing a Comment about a Disc—Disc Memo Function

Clearing the Disc Memo

- 1 Put the disc whose memo you want to clear in the player.
- 2 Press ◀◀ or ▶▶ on the player.
The ◀◀▶▶ button on the remote commander cannot be used.
- 3 Press CLEAR.
- 4 Press FILE.
"FILE CLR" is displayed in the window.

Where is the disc memo stored?

The disc memo is stored in the compact disc player's memory. When a disc is put in the player, the player identifies the disc by the total number of selections and the total playing time. If a disc memo has been made for that disc, the player retrieves the memo from its memory and displays it in the window. Therefore, as the disc memo is not located on the disc itself, when the disc is put in another compact disc player, no memo will be displayed.

Keeping the Program in Memory

—Program Bank Function

After programming selections, you can keep the program memorized, so that the disc is played always in the fixed order. The memorized program is called "program bank".



Memorizing a program


- 1 Program the selections as you want (page 15).
- 2 Press FILE.



Disappears approx. one second later.

The program is memorized for the program bank.

Only one program bank can be made for a disc.



Playing the disc using the program bank

- 1 Press PROGRAM.
- 2 Press Δ and put the disc in the disc compartment.
- 3 Press $\triangleright$.

Clearing the Program Bank

- 1 Put the disc whose program bank is to be cleared in the player.

- 2 Press $\blacksquare$ to clear the program.

- 3 Press FILE.
"PGM CLR" is displayed, and the program bank is cleared.

Where is the program bank memorized?

The program bank is memorized in the compact disc player's memory. Therefore, if a disc for which you made a program bank is used with another compact disc player, play using the program bank is not possible.

What is this indication?

IX FILED

This indication appears when the custom index (next page) has already been made for the disc. The program bank and the custom index cannot both be made for the same disc at the same time. To make the program bank, first clear the custom index.

To play a disc having a program bank in other modes

- 1 Set the player in the desired play mode.
- 2 Put the disc in the disc compartment.
- 3 Press $\triangleright$.


If you press Δ to close the compartment after setting the player in the continuous play mode or the single play mode, program bank play mode will be entered.

To play the selections in another program without clearing the program bank


Program the selections as you want before putting the disc in the disc compartment, or after putting the disc in the player and pressing $\blacksquare$. The disc will be played in the newly programmed order. You can program even during the program bank play.

Giving a Disc Indexes as You Want—

A custom index is a special Index that can be assigned to any position you want on the disc. If you assign custom indexes to the positions on a disc, you can easily locate the positions during play, or enjoy repeat play between two adjacent custom indexes.



- 1 Press FILE where you want to assign a custom index during play.
The portion for 3 seconds from the point where you pressed FILE is played repeatedly (rehearsal play).
- 2 Adjust the repeat start point using ◀◀ or ▶▶.
Press ▶▶ to shift the repeat start point forward and ◀◀ to shift it backward. Pressing ◀◀▶▶ 7 times shifts the point by approximately 1 second.



Blinks

- 3 Press FILE.
The custom index is assigned to the repeat start point.



Lights steadily

How many custom indexes can be assigned?

Up to 6 custom indexes from [A] to [F] can be assigned to a disc.

What is this indication?

PG FILED

This indication appears when a program bank has already been memorized for the disc. The program bank and the custom index cannot both be made for the same disc at the same time. To assign custom indexes, first clear the program bank.


To release rehearsal play

Press CLEAR. Normal play is resumed.

Custom Index Function

Playing from the Desired Custom Index

- 1 Press INDEX MODE.**



The music calendar disappears.

- 2** Press the desired numeric button 1 (A) through 6 (F). Play begins from the designated custom index. When a custom index position is passed, it disappears from the [A] - [F] display.

Clearing Custom Indexes

- 1 Press **CHECK** so that the letter of the custom index you want to clear blinks.
- 2 Press **CLEAR**.
Custom indexes succeeding the cleared index will be shifted ahead one position.

The custom indexes cannot be cleared during program play.

Repeating the Portion Between Two Custom Indexes

During play using custom indexes, you can repeat the desired portion between any two adjacent custom indexes.

- 1 Press **INDEX MODE** twice so that "SINGLE" is displayed in the window.
- 2 Press one of the numeric buttons 1 (A) to 6 (F) for the starting point of the repeat play.
- 3 Press **REPEAT**.

The portion between the custom index designated as the starting point and the next custom index is played repeatedly.

To cancel repeat play between custom indexes
Press REPEAT.

if a new custom index is assigned to a position preceding another index

Previously existing indexed will be shifted as follows.
Example: If you assign a new index between B and C.

A B C

a new index

A B C D

The old index C becomes D.

If you press **F1E** in the pause mode

The rehearsal play is not made and the custom index is assigned immediately at the position where FILE is pressed.

To change the play mode during play using custom indexes

During play using custom indexes (in other words, while the music calendar is not displayed), the play mode switches from continuous play to single play and vice versa each time INDEX MODE is pressed.

To release play using custom indexes


Press one of the **PLAY MODE** buttons (**PROGRAM**, **SHUFFLE** or **CONTINUE/SINGLE**). The music calendar appears.

Where are the custom indexes memorized?

The custom indexes are memorized in the compact disc player's memory. Therefore, if a disc for which custom indexes are assigned is played in other compact disc player, play using the custom indexes cannot be done.

Timer Activated Playing

By connecting a commercially available timer, disc play can be started at any desired time.



- 1 Put a disc in the player.
- 2 Choose the desired play mode using the PLAY MODE buttons.
- 3 Set the timer for the desired time.
- 4 Set TIMER to PLAY.



Play begins automatically at the time set.

When the timer activated play ends
Be sure to set TIMER to OFF.

To start program play using the timer
First make a program bank, and then prepare for timer activated playing.

If play using custom indexes is selected for the timer activated playing
Play begins from custom index A.

Maintenance

Cleaning the cabinet

Clean the cabinet, panel and controls with a soft cloth lightly moistened with mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzine.

Cleaning discs

Before playing, clean the disc with the cleaning cloth. Wipe the disc from the center out.



Do not use solvents such as benzine, thinner, commercially available cleaners or anti-static spray intended for analog discs.

After playing, store the disc in its case.

Specifications

Compact disc player

	CDP-557ESD CDP-707ESD	CDP-337ESD
System	Compact disc digital audio system	
Laser	Semiconductor laser ($\lambda = 780 \text{ nm}$)	
Emission duration	Continuous	
Laser output	less than $44.6 \mu\text{W}$ * This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up block.	
Frequency response	CDP-557ESD: 2 Hz - 20 kHz $\pm 0.5 \text{ dB}$ CDP-707ESD: 2 Hz - 20 kHz $\pm 0.3 \text{ dB}$	2 Hz - 20 kHz $\pm 0.5 \text{ dB}$
Signal to noise ratio	More than 115 dB	More than 110 dB
Dynamic range	More than 100 dB	More than 98 dB
Harmonic distortion	Less than 0.0015%	Less than 0.0025%
Wow and flutter	Below measurable limit	
Channel separation	More than 110 dB	More than 100 dB

Outputs

	CDP-557ESD CDP-707ESD	CDP-337ESD
LINE OUT (FIXED) (phone jacks)	Output level 2 V (at 50 kilohms) Load impedance over 10 kilohms Output impedance 200 ohms	
LINE OUT (VARIABLE) (phone jacks)	Output level max. 2 V (at 50 kilohms) Load impedance over 50 kilohms	
	Output impedance 200 ohms - 5.1 kilohms	Output impedance 200 ohms - 2.7 kilohms
DIGITAL OUT (COAXIAL) (phone jacks)	Output level 0.5 Vp-p (at 75 ohms) Load impedance 75 ohms	
DIGITAL OUT (OPTICAL) (optical output connector)	Wave length 660 nm Output level -18 dBm	
HEADPHONES (stereo phone jack)	Output level max. 28 mW Load impedance 32 ohms	

Specifications

General

	CDP-557ESD/ CDP-707ESD	CDP-337ESD
Power requirements	Model for European countries 220 V AC (or 240 V AC adjustable by Sony personnel), 50/60 Hz Model for the United Kingdom 240 V AC (or 220 V AC adjustable by Sony personnel), 50 Hz Model for the U.S.A and Canada (CDP-707ESD) 120 V AC, 60 Hz Model for other countries (CDP-337ESD) 120, 220 or 240 V AC adjustable, 50/60 Hz	
Power consumption	22 W	27 W
Dimensions (approx.)	CDP-557ESD (for the United Kingdom) 430 x 120 x 375 mm (w/h/d) (17 x 5 x 14 7/8 inches) CDP-707ESD/ CDP-557ESD (for European countries) 470 x 125 x 375 mm (w/h/d) (18 1/2 x 5 x 14 7/8 inches)	430 x 125 x 375 mm (w/h/d) (17 1/2 x 5 x 14 7/8 inches)
Weight (approx.)	CDP-557ESD (for the United Kingdom) 17 kg (37 lbs 8 oz) CDP-707ESD/ CDP-557ESD (for European countries) 18 kg (39 lbs 11 oz)	11.5 kg (25 lbs 6 oz)

Supplied accessories

	CDP-557ESD/ CDP-707ESD	CDP-337ESD
Audio signal connecting cord	1 (2 phono plugs—2 phono plugs)	
Remote commander	1	
Sony SUM-3 (4LR) batteries	2	
Screw driver	1	

Remote commander

Remote control system	Infrared control
Power requirements	3V DC with two R6 (size AA) batteries
Dimensions	Approx. 62 x 20 x 168.5 mm (w/h/d) (2 1/2 x 3/16 x 6 5/8 inches)
Weight	Approx. 130 g (5 oz) including batteries

Note

This appliance conforms with EEC Directives 76/689 and 89/499 regarding interference suppression.

Optional accessory

Optical cable POC-1B

Your dealer may not handle the above optional accessory. Please ask the dealer for detailed information about the optional accessory available in your country.

Design and specifications subject to change without notice.

Troubleshooting Guide

The following checks will assist in the correction of most problems which you may encounter with your unit. Before going through the check list below, first refer back to the connections and operating procedures.

Should any problem persist after you have made these checks, consult your nearest Sony service facility.

Symptom	Cause	Remedy
The disc compartment does not close when a disc is inserted and the  button is pressed.	The disc is not placed correctly.	Put the disc correctly in the disc compartment.
Play does not start.	Dirty disc	Clean the disc.
	The disc is inserted with the label surface downward.	Place the disc with the label surface up.
	The  button is engaged.	Press the  button again to release it.
	Moisture condensation	Wait for approx. one hour after turning on the unit then start play.
Sound is not heard.	Loose connection	Connect the cords firmly.
	The OUTPUT SELECTOR is set to the DIGITAL OUT side while using the LINE OUT jacks.	Set the OUTPUT SELECTOR to LINE OUT side.
	The LINE OUT/HEADPHONE LEVEL control is set to the minimum (0) while using the VARIABLE LINE OUT jacks.	Turn the LINE OUT/HEADPHONE LEVEL control clockwise.
Display window does not illuminate even when the power is turned on.	The AC power cord is disconnected.	Connect the AC power cord firmly.
Play begins when the POWER switch is turned on.	The TIMER switch is set to PLAY.	Set the TIMER switch to OFF.
Level of the recorded sound is different from that set on the tape recorder.	When the VARIABLE LINE OUT jacks are used, the LINE OUT/HEADPHONE LEVEL control is turned while recording.	Do not turn the LINE OUT/HEADPHONE LEVEL control while recording.

Avertissement

Afin d'éviter tout risque d'incendie ou d'électrocution, ne pas exposer cet appareil à la pluie ou à l'humidité.

Afin d'écartier tout risque d'électrocution, garder le coffret fermé. Ne confier l'entretien de l'appareil qu'à un personnel qualifié.

DANGER

Radiations invisibles du laser en cas d'ouverture et de défaillance ou de mise hors service du dispositif de verrouillage. Eviter toute exposition directe au faisceau.

ATTENTION

Un emploi des commandes, des réglages et une exécution des démarches, contraires aux explications de ce manuel risquent d'occasionner une exposition à des radiations dangereuses.

**CLASS 1
LASER PRODUCT**

Ce lecteur de compact disc fait partie des produits de la CLASS 1 LASER. Cette mention est située sur le socle de l'appareil.

Le laser de cet appareil peut émettre des radiations supérieures à la limite de la classe 1.

POUR LES UTILISATEURS AU CANADA

ATTENTION:

POUR PREVENIR LES CHOCS ELECTRIQUES, NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

Différences entre les CDP-557ESD, CDP-707ESD et CDP-337ESD

Le présent manuel traite à la fois du modèle CDP-557ESD, du CDP-707ESD et du CDP-337ESD dont les performances et l'utilisation sont identiques. Les seules différences existent au niveau du panneau avant et des spécifications techniques. En ce qui concerne ces dernières, prière de consulter les "Spécifications".

Les modèles suivants sont pourvus de panneaux latéraux, tandis que les autres ne sont pas:
CDP-707ESD (pour les Etats-Unis et le Canada)
CDP-557ESD (pour les pays européens)

Dans ce manuel, le CDP-707ESD a été choisi pour les illustrations.